


Take-Ups

Accurately Maintain Belt Tension to Prevent Slippage



Quick Specs

- ▶ **Style:** Pillow Block, Wide Slot, Top Angle
- ▶ **Mounting Positions:** Side or Top
- ▶ **Size Range:** 1/2" - 9" Bearing Diameter

Frequently Asked Questions

What size do I need?

- ▶ The common "rule of thumb" is to choose a travel size that is 2% of your center to center belt length.

What is distinct about Superior's design?

- ▶ The ACME screw has nonbinding characteristics resulting in less seizing and longer life. ACME screws are standard on all of our take-ups.

What is significant about screw protection?

- ▶ The screw is the heartbeat of the take-up. Once damaged or bent, you lose the effectiveness of the component. Telescoping tube take-ups are the only style manufactured with a completely enclosed screw, although each model has some protection to block material.



Digital Literature
Forward to Colleague



Take-Ups


Features and Benefits

High Quality Construction

- ▶ ACME rod is standard
- ▶ ACME thread design provides quick movement and reliability in corrosive conditions
- ▶ Durable Powder Coat finish

Stocked for Quick Deliveries


- ▶ Carried by your local Superior distributor (superior-ind.com/distributor)
- ▶ Quick lead times from factory




Take-Up Styles

Take-Up Selection Guide

① Scenario One: Style



② Scenario Two: Bearing Size




③ Scenario Three: Bearing Type

Take-Up Style	Bearing Type					
	SealMaster	Browning	Link-Belt	Rexnord	Dodge	SKF
TUTT	NP, MP	VPS, SPB1000, PBE	PB22400, EPB22400, C35	ZA, ZEP	SC, SCM, S2000, Type E, Imperial	–
TULD (Roller)	NP, MP	VPS, SPB1000	PB22400, C35	ZA	SCM, S2000, Imperial	–
TUHD (Roller)	USRB	VPS, SPB1000, PBE, SAF22500	PB22400, EPB22400, PLB	ZA, ZAF, ZEP	S2000, Type E, USAF, TAF, Imperial	SAF
TUWS (Ball)	MST	VTWS	–	–	WSTU-SC, WSTU-SCM	–
TUCP (Roller)	–	TUE-920, ST-1000	–	ZT-2000, ZT-5000	Type E (WSTU-E), S-2000 (WSTU-S2)	–
TUTA	–	–	ETPB-22400	–	Type E (TPE), Type G (SC), Type GM (SCM), S-2000	–

Part Number Guide

Example:



TUTT, TUWS, TULD
TUTA, TUHD, TUCP

100-1004

1.5" - 60"

*Not all configurations are possible, see catalog for available parts

1-800-321-1558

Find local distribution at superior-ind.com/distributor

© 2013 Superior Industries CL-122

