


## SERIES 9000 Attrition Cells Spec Sheet

## • ATTRITION CELL

- Heavy duty rubber lined tank designed to minimize vortexing, back-mixing, short circuiting and dead zones.
   Round tank with baffles on the Model #AC 900-1 and hexagonal tank(s) on the Model #AC 2100-2 and #AC 4200-4
- Access ports with bolt-on covers
- High speed, rubber lined, oppositely pitched turbines.
   Twin impellar blades on the Model #AC 900-1 and triple blades on the Model #AC 2100-2 and #AC 4200-4.
   Custom turbine designs available consult factory
- HP, TEFC, 3/60/230-460 heavy duty drive assembly with Faulk direct coupled right angle gear reducer



## POWER REQUIREMENTS & APPROX CAPACITIES

Model	HP	Volume	No. of Cells	Shape of Cells	Approx. Capacity
AC 900-1	50	900 gals.	1	Round with baffles	133 stph
AC 2100-2	2 @ 100	2100 gals.	2	Hexagonal	310 stph
AC 4200-4	4 @ 100	4200 gals.	4	Hexagonal	620 stph

## FOR MORE INFORMATION CALL 1-800-542-9311 AND ASK FOR A KOLBERG EQUIPMENT SPECIALIST

NOTE: Specifications are subject to change without notice.

Because KPI-ICI may use in its catalog & literature, field photographs of its products which may have been modified by the owners, products furnished by KPI-ICI may not necessarily be as illustrated therein. Also continuous design progress makes it necessary that specifications be subject to change without notice. All sales of the products of KPI-ICI are subject to the provisions of its standard warranty. KPI-ICI does not warrant or represent that its products meet any federal, state, or local statutes, codes, ordinances, rules, standards or other regulations, including OSHA and MSHA, covering safety, pollution, electrical wring, etc. Compliance with these statutes and regulations is the responsibility of the user and will be dependent upon the area and the use to which the product is put by the user. In some photographs, guards may have been monwed for illustrative purposes only. This equipment should not be operated without all guards attached in rormal position. Pleacement of guards and other safety equipment should not be operated without all guards, warning signs and other safety betwices should be installed by the user, wherever appropriate before operating the products.



Email: mail@kpijci.com www.kpijci.com Mdl 9000 attrition cell 05/12